

V Chassis Sport fitting guide

The Sport chassis is designed to accept standard length 2s hardcase lipos.

Shocks between 70-100mm can be used.

This chassis kit is designed to work with your Clodbuster axles with only minor modifications.

A 3mm hole needs to be drilled at the bottom of each axle tube to attach the lower link mounts.

Put the 20mm screw in from the outside.



Put the 4mm spacer over the screw first, then the lower link. Slide the rod end over the sway bar wire before attaching it.

You will need wider than stock wheels or wheel wideners to prevent the tyre touching the lower link on full lock.



The top link mounts attach to the gearboxes as shown, 1x 6mm spacer at the rear and the 3 x cut washers at the front.

Be careful not to over-tighten the screws as this could cause damage to the plastic gear cases.

